


# BEVEL BALL ACTUATORS COLUMN LOADING



This chart includes a 2:1 Factor-of-Safety based on the Euler-Johnson equation for column loading (Oberg, Erik et al: Machinery's Handbook, 24th Edition. c. 1992 Industrial Press Inc.)  
 The horizontal portion of each line represents the jack's maximum static capacity.